



FPJ Series Firefighter's Phone Jack

PN 15510:F 05/22/2006 06-282

1 Product Overview




2 FPJ Through Connection: All control panels.




3 End-of-Line Connections

■ For INTELLIGENT systems requiring 47K ELR, except in Canada.
Refer to panel installation manuals for details.




15510w2.wmf

■ For CONVENTIONAL systems requiring 4.7K ELR, except in Canada.
Refer to panel installation manuals for details.




15510w3.wmf

■ For INTELLIGENT systems requiring 3.9K ELR, except in Canada.
Refer to panel installation manuals for details.



15510w3.wmf

■ All control panels IN CANADA.
Refer to panel installation manuals for details.



15510w4.wmf



NOTE: Use ELR provided with module. For intelligent systems requiring 47K ELR, use internal resistor.
Installation in Canada, use EOL-CR/CW.